

1. Before each conversation, say "Hey-AC" to activate the air-conditioning voice function. After the air-conditioning is activated, a short piece of music will be broadcast to indicate that the voice function is activated successfully and you can start voice air control. If the voice function is not activated, voice control cannot be performed.
2. If the air conditioner does not receive a voice command for 10 consecutive seconds, the air conditioner will exit the voice function. You need to say "Hey-AC" to activate the air conditioner before you can start the voice function again.
3. The voice commands and air-conditioning broadcast are as follows:

English Voice Command	eLuxury Response
Hey-AC	music
TURN-ON-THE-AC	TURN-ON-THE-AC
TURN-OFF-THE-AC	TURN-OFF-THE-AC
COOLING-MODE	COOLING-MODE
HEATING-MODE	HEATING-MODE
FAN-MODE	FAN-MODE
DRY-MODE	DRY-MODE
AUTO-MODE	AUTO-MODE
HIGH-SPEED	HIGH-SPEED
MEDIUM-SPEED	MEDIUM-SPEED
LOW-SPEED	LOW-SPEED
AUTO-SPEED	AUTO-SPEED
DISPLAY-OFF	DISPLAY-OFF
DISPLAY-ON	DISPLAY-ON
VERTICAL-SWING	VERTICAL-SWING
STOP-VERTICAL-SWING	STOP-VERTICAL-SWING
SIXTEEN-DEGREES	SIXTEEN-DEGREES
SEVENTEEN-DEGREES	SEVENTEEN-DEGREES
EIGHTEEN-DEGREES	EIGHTEEN-DEGREES
NINETEEN-DEGREES	NINETEEN-DEGREES
TWENTY-DEGREES	TWENTY-DEGREES
TWENTY-ONE-DEGREES	TWENTY-ONE-DEGREES
TWENTY-TWO-DEGREES	TWENTY-TWO-DEGREES
TWENTY-THREE-DEGREES	TWENTY-THREE-DEGREES
TWENTY-FOUR-DEGREES	TWENTY-FOUR-DEGREES
TWENTY-FIVE-DEGREES	TWENTY-FIVE-DEGREES
TWENTY-SIX-DEGREES	TWENTY-SIX-DEGREES
TWENTY-SEVEN-DEGREES	TWENTY-SEVEN-DEGREES
TWENTY-EIGHT-DEGREES	TWENTY-EIGHT-DEGREES
TWENTY-NINE-DEGREES	TWENTY-NINE-DEGREES
THIRTY-DEGREES	THIRTY-DEGREES
THIRTY-ONE-DEGREES	THIRTY-ONE-DEGREES
THIRTY-TWO-DEGREES	THIRTY-TWO-DEGREES
TOO-COLD	TOO-COLD
TOO-HOT	TOO-HOT
VOLUME-UP	VOLUME-UP
VOLUME-DOWN	VOLUME-DOWN
MINIMUM-VOLUME	MINIMUM-VOLUME
MAXIMUM-VOLUME	MAXIMUM-VOLUME
	Invalid operation